

KENWOOD


KA-94

STEREO INTEGRATED AMPLIFIER






- * Refer to Parts List on page 6. Photo is KA-94 (Black version).
 - S: Silver version
 - B: Black version






DISASSEMBLY FOR REPAIR

- 1. Remove the metallic case and remove 6 screws retaining the panel assembly (1).
- 2. Remove the panel assembly and pull off the BASS, TRE-BLE, BALANCE, METER RANGE knobs (2, 3).




- 3. Remove 2 screws at the ends of the sub panel and 4 screws retaining the switches (4, 5).
- 4. Cut the wire bands bonding the lead wires with a wire cutter (6). Pull the sub panel frontward and then components on pc board can be replaced (7).




5. For repair of X07 (B/4) pc board, remove 2 push rivets and tilt it toward the rear (3),

6. For replacement of power transistors, use a hex-wrench (W05-0022-00) (**1**).





BLOCK & LEVEL DIAGRAM/CIRCUIT DESCRIPTION



CIRCUIT DESCRIPTION Component function Control unit (X11-2110-10)

| Components | Functions | Functions Operations | | | |
|------------|---------------|---|--|--|--|
| IC1 | EQ amp | | | | |
| IC2 | TONE amp | | | | |
| Q1 - Q4 | Meter circuit | Rectifies the main amp output and is controlled by the range select switch. | | | |
| Q5 | AVR | For backlight lamp | | | |

Main amp unit (X07-2210-10)

| Components | Functions | Operations |
|------------|----------------------------|---|
| Q1 - Q4 | 1st stage differential amp | Class A amp |
| Q5 - Q8 | 2nd stage differential amp | Class A amp |
| Q9 - Q12 | Class A amp | |
| Q13 - Q16 | Driver amp | · |
| Q17 - Q20 | Power amp | |
| Q21 - Q24 | Level detection | Operates as a current limiter for final protection in overload drive. |
| Q27 | AVR | For Class A amp |
| Q38 - Q41 | AVR | |
| Q43, Q44 | BIAS amp | |
| IC1 | Protection IC | Operates when amp mulfunctions Relay OFF. |

ADJUSTMENT/REGLAGES/ABGLEICH

ADJUSTMENT


| | | INPUT | OUTPUT | AMPLIFIER | ALIGNMENT | A1 70U DOD | 2.0 |
|-----|-----------------|----------------------|---|-----------|--------------------|------------|------|
| No. | ITEM | SETTINGS | SETTINGS | SETTINGS | POINTS | ALIGN FOR | FIG. |
| Set | the controls an | d switches as follow | s: POWER: ON SPEAKER: | В | | | |
| 1 | IDLE CURRENT | - | Connect a DC voltmeter across CP1 (L) CP2 (R) | VOLUME: 0 | VR1 (L) VR2 (R) | 9m¥ | (a) |

REGLAGES

| N. | ITEM | REGLAGE DE L'ENTREE | REGLAGE DE LA SORTIE | REGLAGE DE L'AMPLIFICATEUR | POINS L'ALIGNEMENT | ALIGNER POUR | FIG. |
|-----|-------------------------|------------------------|---|-------------------------------|-----------------------|--------------|------|
| Rég | ler les controle | s et les boutons com | me suit: POWER: ON S | SPEAKER: B | | | |
| 1 | COURANT DE POLARISATION | _ | Connecter un voltmètre de CC sur CP1 (G) CP2 (D) | VOLUME: 0 | VR1 (G) VR2 (D) | 9 m V | (a) |


ABGLEICH


| NR. | GEGENSTAND | EINGANGS- EINSTELLUNG | AUSGANGS- Einstellung | VORSTÄRKER Einstellung | ABGLEICH- PUNKTE | ABGLEICHEN FÜR | ABB. |
|-----|-----------------|--------------------------|---|---------------------------|---------------------|----------------|------|
| Die | Regler und Knöp | fe wird folgt einste | llen: POWER: ON SPEA | KER: B | | | |
| 1 | LEERLAUFSTROM | _ | Einen Gleichspannungs- messer über CP1 (L) CP2 (R) anschließen | VOLUME: 0 | VR1 (L) VR2 (R) | 9m V | (a) |




KA-94 KA-94


PC BOARD







EXPLODED VIEW



Parts with the exploded numbers larger than 700 are not supplied.

PARTS LIST

× New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

| | Ref. No. | Address | New Parts | Parts No. | Description | | Re- | |
|-------------|----------------------------|----------------------------|--------------|---|---|---|-----|--|
| | 参照番号 | 位 置 | fails 新 | 部品番号 | 部品名/規格 | nation 仕 向 | 備考 | |
| | KA-94 (Silver) | | | | | | | |
| | 1 2 2 2 | 1A 2A 2A 2A 2A | * * | A01-1319-02 A20-4244-02 A20-4244-02 A20-4245-02 | METALLIC CABINET PANEL ASSY PANEL ASSY PANEL ASSY | KPUM <u>UE</u> XE T | | |
| | 6 7 - - | 2A 2A | | B03-1718-03 B03-1721-04 B46-0092-03 B46-0094-03 B46-0095-03 | DRESSING PLATE(TWNE CWNT,DISP) DRESSING PLATE(METER RANGE) WARRANTY CARD WARRANTY CARD WARRANTY CARD | N <u>NE</u> N <u>NE</u> | | |
| | | | | 846-0096-03 846-0121-03 846-0122-13 846-0123-03 850-5535-00 | WARRANTY CARD WARRANTY CARD WARRANTY CARD WARRANTY CARD INSTRUCTION MANUAL(ENGLISH) | X P E T KPUM | | |
| | - | | | 850-5535-00 850-5536-00 850-5537-00 850-5538-00 850-5539-00 | INSTRUCTIÓN MANUAL(ENGLISH) INSTRUCTIÓN MANUAL(FRENCH) INSTRUCTIÓN MANUAL(SPANISH) INSTRUCTIÓN MANUAL(ARABIC) INSTRUCTIÓN MANUAL(ENGLISH) | UEXE PMXE M M T | | |
| | | | | B50-5540-00 B58-0223-04 B58-0245-33 B58-0269-04 B58-0513-04 | INSTRUCTION MANUAL(G,D,I) CAUTION CARD (PRE-SET 120V) CAUTION CARD (FTZ) CAUTION CARD CAUTION CARD (PRESET220-240) | E U E V UE | | |
| | - | | | B59-0092-00 | SERVICE DIRECTORY | U <u>UE</u> | | |
| A A A | 12 12 13 13 13 | 10 10 10 10 10 | | E03-0068-05 E03-0069-05 E30-0181-05 E30-0459-05 E30-0587-15 | AC NUTLET AC NUTLET AC POWER CORD AC POWER CORD AC POWER CORD | P KUM <u>UE</u> K E T | | |
| A A A | 13 13 13 | 1C 1C 1C | | E30-0812-05 E30-0974-05 E30-1341-05 | AC POWER CORD AC POWER CORD AC POWER CORD | UM <u>UE</u> P X | | |
| A A A | F1 F1 F1 F2 | 10 10 10 10 | | F05-3121-05 F05-6021-05 F05-6027-05 F05-3022-05 | FUSE (SEMK®) (250V T3.15A) FUSE (250V 6A) FUSE (UL) (250V 6A) FUSE (250V 3A) | XTE UM <u>UE</u> KP UM <u>UE</u> | | |
| | | | * * | H01-5349-04 H01-5349-04 H01-5350-04 H10-1788-04 H10-1812-02 | ITEM CARTÓN CASE ITEM CARTÓN CASE ITEM CARTÓN CASE POLYSTYRENE FOAMED FIXTURE POLYSTYRENE FOAMED FIXTURE | KPUM UEXE T | | |
| | | | | H10-1813-02 H25-0223-04 H25-0232-04 | POLYSTYRENE FOAMED FIXTURE PROTECTION BAG (750X350) PROTECTION BAG (235X350) | | | |
| ҈Ѧ | 17 18 19 20 | 2B,2C 2B 2A,2B 1C | | J02-0161-04 J19-0515-05 J21-3326-05 J42-0083-05 J61-0307-05 | F00T UNIT HOLDER JACK: MOUNTING HARDWARE(PHONES) POWER CORD BUSHING WIRE BAND | | | |
| | 24 | 2A | | K27-1264-04 | KNOB (BUTTON) METER RANGE | | | |

E: Scandinavia & Europe H:Audio Club K: USA

S: South Africa

T: England U: PX(Far East, Hawaii)

UE . AAFES(Europe) X: Australia M: Other Areas

P: Canada

⚠ indicates safety critical components.

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

| | Ref. No. | Address | | Parts No. | Description | | Re- |
|----------------------|----------------------|----------------------------|------------|---|---|---|-------------|
| | 参照番号 | 位 置 | Parts 新 | 部品番号 | 部 品 名 / 規 格 | | marks 備考 |
| | 25 26 27 28 | 2A 2A 2A 2A | | K27-1290-04 K29-1446-04 K29-1683-04 K29-2016-04 | KNOB (BUTTON) SPEAKERS A/B KNOB ASSY(BUTTON) POWER KNOB VOLUME KNOB BASS,TREBLE,BALANCE | | |
| | 33 33 33 33 | 1B 1B 1B 1B | | L01-3961-05 L01-3962-05 L01-3965-05 L01-3967-05 | POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER | KP XT UM <u>UE</u> E | |
| | 37 A | 10 1A,1B | | N08-0128-35 N09-1473-05 | BINDING POST (GND) TAPPING SCREW (M3XB) | | |
| ∧ | S1 S2 | 1A 1B | | \$40-1073-05 \$31-2083-05 | PUSH SWITCH (PØWER) SLIDS SWITCH (PØWER TYPE) | UM <u>UE</u> | |
| | | | | | (Black) | F | |
| | 1 2 2 2 | 1A 2A 2A 2A | * * * | A01-1415-02 A20-4235-02 A20-4235-02 A20-4236-02 | METALLIC CABINET PANEL ASSY PANEL ASSY PANEL ASSY | KPUM UEXE T | |
| | 6 7 - - | 2A 2A | * | B03-1718-03 B03-1721-04 B46-0092-03 B46-0094-03 B46-0095-03 | DRESSING PLATE(TONE CONT.DISP) DRESSING PLATE(METER RANGE) WARRANTY CARD WARRANTY CARD WARRANTY CARD | K U <u>UE</u> U <u>UE</u> | |
| | | | * | B46-0096-03 B46-0121-03 B46-0122-13 B46-0123-03 B50-5535-00 | WARRANTY CARD WARRANTY CARD WARRANTY CARD WARRANTY CARD WARRANTY CARD INSTRUCTION MANUAL(ENGLISH) | X P E T KPUM | |
| | - | | * * * * | 850-5535-00 850-5536-00 850-5537-00 850-5538-00 850-5539-00 | INSTRUCTIØN MANUAL(ENGLISH) INSTRUCTIØN MANUAL(FRENCH) INSTRUCTIØN MANUAL(SPANISH) INSTRUCTIØN MANUAL(ARABIC) INSTRUCTIØN MANUAL(ENGLISH) | UEXE PMXE M M T | |
| | - | | * | B50-5540-00 B58-0223-04 B58-0245-33 B58-0269-04 B58-0513-04 | INSTRUCTION MANUAL(G.D.1) CAUTION CARD (PRE-SET 120V) CAUTION CARD (FTZ) CAUTION CARD CAUTION CARD CAUTION CARD (PRESET220-240) | E U E K <u>U</u> E | |
| | *** | | | B59-0092-00 | SERVICE DIRECT®RY | U <u>UE</u> | i. |
| ★ | 12 12 13 13 | 10 10 10 10 10 | | E03-0068-05 E03-0069-05 E30-0181-05 E30-0459-05 E30-0587-15 | AC DUTLET AC DUTLET AC POWER CORD AC POWER CORD AC POWER CORD | P KUM <u>UE</u> K E T | |
| ∧ ∧ | 13 13 13 | 1C 1C 1C | | E30-0812-05 E30-0974-05 E30-1341-05 | AC POWER CORD AC POWER CORD AC POWER CORD | UM <u>UE</u> P X | |
| ∆ ∧ ∧ | F1 F1 F1 F2 | 10 10 10 10 | | F05-3121-05 F05-6021-05 F05-6027-05 F05-3022-05 | FUSE (SEMK®) (250V T3.15A) FUSE (250V 6A) FUSE (UL) (250V 6A) FUSE (250V 3A) | XTE UM <u>UE</u> KP UM <u>UE</u> | |
| | | | * | H01-5343-04 H01-5343-04 | ITEM CARTON CASE ITEM CARTON CASE | KPUM UEXE | |

E: Scandinavia & Europe H:Audio Club K: USA

P: Canada

S: South Africa

T: England U: PX(Far East, Hawaii)

UE : AAFES(Europe)

X: Australia M: Other Areas

* New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

| Ref. No. | Address | | Parts No. | Description | | Re- |
|--|-------------|------------|--|---|--------------------------|-------------|
| 参照番号 | 位 置 | Parts 新 | 部品番号 | 部品名/規格 | | marks 備考 |
| C51 •52 | | | CK45FB1H102K | CERAMIC 1000PF K | | |
| E | 1B,10 1B | | N09-0333-05 N29-0067-05 | TAPPING SCREW (Ø3X12) PUSH RIVET (Ø3.5X4.5) | | |
| CP1 +2 R19 +20 R33 +34 R35 -38 R39 -42 | | * | R90-0187-05 RD14AB2E621J RD14AB2E132J RD14AB2E470J RD14AB2E221J | MULTI-COMP 0.22X2 K 5W FL-PROOF RD 620 J 1/4W FL-PROOF RD 1.3K J 1/4W FL-PROOF RD 47 J 1/4W FL-PROOF RD 220 J 1/4W | | |
| R43 -46 R59 -60 R71 -72 R85 R85 | | *: | RD14AB2E2R2J RD14AB2E221J RS14KB3D4R7J RS14KB3D122J RS14KB3D152J | FL-PR00F RD 2.2 J 1/4W FL-PR00F RD 22D J 1/4W FL-PR00F RS 4.7 J 2W FL-PR00F RS 1.2K J 2W FL-PR00F RS 1.5K J 2W | XTE KPUM | |
| R85 R93 +94 R95 R96 R99 | | * * | RS14KB3D152J RS14KB3D271J RS14KB3D680J RS14KB3D820J RS14KB3A822J | FL-PR00F RS 1.5K J 2W FL-PR00F RS 270 J 2W FL-PR00F RS 68 J 2W FL-PR00F RS 82 J 2W FL-PR00F RS 8.2K J 1W | <u>UE</u> | |
| R103 R105,106 R107,108 R111 R121 | | * * * | RS14KB3A822J RD14AB2E182J RD14AB2E152J RD14AB2E220J RD14GB2E220J | FL-PR00F RS 8.2K J 1W FL-PR00F RD 1.8K J 1/4W FL-PR00F RD 1.5K J 1/4W FL-PR00F RD 22 J 1/4W FL-PR00F RD 22 J 1/4W | | |
| R122 VR1 •2 | | * | RD14AB2E220J R12-0094-05 | FL-PROOF RD 22 J 1/4W TRIMMING POT.(470) IDLING | | |
| K1 | 1 B | | \$51-2058-05 | MAGNETIC RELAY | | |
| D3 ,4 D3 ,4 D3 ,4 D5 ,6 D7 ,8 | | | 1SS133 1S1555 1S2076 RD18E(B) 1S2076A | DIODE DIODE DIODE ZENER DIODE DIODE | | |
| D9 +10 D11 +12 D14 -16 D17 D24 | | * | RDB. 2E(B) 1S2076A 1S2076A DSM1A1 DSM1A1 | ZENER DIØDE DIØDE DIØDE DIØDE DIØDE | | |
| D25 -32 D34 D35 D36 ,37 D39 ,40 | | | S3V20 1S2076A RD24E(B) TF620M RD16E(B) | DIODE DIODE ZENER DIODE SCR ZENER DIODE | | |
| D41 ,42 IC1 Q1 -8 Q1 -8 Q9 ,10 | | | RD18E(B) UPC1237H 2SC232O(E,F) 2SC945(A)(0,P) 2SA733(A)(0,P) | ZENER DIODE IC(PROTECTION) TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR | | |
| 09 ,10 011 ,12 013 ,14 013 ,14 013 ,14 | | | 2SA999(E,F) 2SA1123(0,R) 2SC2590(0,R) 2SC2591(0,R) 2SC2591(0,R) | TRANSISTØR TRANSISTØR TRANSISTØR TRANSISTØR TRANSISTØR | XTE KPUM <u>UE</u> | |
| 015 -16 | | | 2SA1110(Q,R) | TRANSISTOR | XTE | |

E: Scandinavia & Europe H:Audio Club K: USA

P: Canada

S: South Africa

T: England U: PX(Far East, Hawaii)

× New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne $\mbox{\bf Parts}\ \mbox{\bf No.}$ werden nicht geliefert.

| | 参照 | 番号 | 位 置 | Parts | | I | nation | marks |
|---|---|------------------------|----------------------------|-------|--|--|-------------------------------|-------|
| | | | PL 15. | 新 | 部品番号 | 部品名/規格 | | 備考 |
| | | | | * * * | H01-5344-04 H10-1788-04 H10-1812-02 H10-1813-02 H25-0223-04 | ITEM CARTON CASE POLYSTYRENE FOAMED FIXTURE POLYSTYRENE FOAMED FIXTURE POLYSTYRENE FOAMED FIXTURE PROTECTION BAG (750X350) | Т | |
| | | | | | H25-0232-04 | PRNTECTION BAG (235X350) | | |
| Δ | 17 18 19 20 | | 2B,2C 2B 2A,2B 1C | | J02-0161-04 J19-0515-05 J21-3326-05 J42-0083-05 J61-0307-05 | FNOT UNIT HOLDER JACK MOUNTING HARDWARE(PHONES) POWER CORD BUSHING WIRE BAND | | |
| | 24 25 26 27 28 | | 2A 2A 2A 2A 2A | * * | K27-1264-04 K27-1304-04 K29-2001-04 K29-2020-04 K29-2016-04 | KNOB (BUTTON) METER RANGE KNOB (BUTTON) SPEAKERS A/B KNOB ASSY(BUTTON)POWER KNOB VOLUME KNOB BASS,TREBLE,BALANCE | | |
| | 33 33 33 33 | | 1B 1B 1B 1B | * * * | L01-3961-05 L01-3962-05 L01-3965-05 L01-3967-05 | POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER POWER TRANSFORMER | KP XT UM <u>UE</u> E | |
| | 37 | | 1C | | N08-0128-35 | BINDING POST (GND) | | |
| | S1 S2 | | 1A 1B | | \$40-1073-05 \$31-2083-05 | PUSH SWITCH (POWER) SLIDE SWITCH (POWER TYPE) | UMUE | |
| | | | | | POWER SUPPLY | (X00-2300-11) | | |
| | 41 41 41 | | 1B 1B 1B | | J13-0041-05 J13-0041-05 J13-0054-05 | FUSE CLIP FUSE CLIP FUSE CLIP | KP UM <u>UE</u> XTE | |
| | | | | , | POWER AMP (| | | |
| | 63 , 65 , 67 , | 2 4 6 8 10 | | | CE04FW1H010M CC45FSL1H221J CE04FW1A101M CC45FSL1H080D CF92FV1H682J | ELECTR® 1.0UF 50WV CERAMIC 220PF J ELECTR® 100UF 10WV CERAMIC 8.0PF D MF 6800PF J | | |
| | C11 , C13 , C15 , C17 , | 14 16 18 | | | CC45FSL1H030C CC45FSL1H270J CE04FW1H330M CK45FF1H103Z CE04FW1H010M | CERAMIC 3. OPF C CERAMIC 27PF J ELECTRO 33UF 50WV CERAMIC 0. 010UF Z ELECTRO 1. OUF 50WV | | |
| | C21 , C23 - C27 C2 9 , C33 | 26 | | * | CK45FF1H1O3Z CF92FV1H1O4J CEO4FW2A47OM CEO4FW1E47OM CEO4FW1E47OM | CERAMIC 0.010UF Z MF 0.10UF J ELECTR® 47UF 100WV ELECTR® 47UF 25WV ELECTR® 47UF 25WV | | |
| | C34 , C34 , C34 , C36 C37 | 35 | | * | C90-1294-05 C90-1318-05 C90-1318-05 CE04HW1A220M CE04FW1V4R7M | ELECTR® 7500UF 63WV ELECTR® 7500 80WV ELECTR® 7500 80WV NP-ELEC 22UF 10WV ELECTR® 4.7UF 35WV | XTE KPUM UE | |
| | 038 042 - 046 047 , 049 | | ļ | | CE04FW1H330M CK45FE2H682P CE04FW1J100M CC45FSL1H101J CE04FW1H010M | ELECTR® 33UF 50WV CERAMIC 6800PF P ELECTR® 10UF 63WV CERAMIC 100PF J ELECTR® 1.0UF 50WV | XTE | |

E Scandinavia & Europe H:Audio Club K: USA

S: South Africa T: England U: PX(Far East, Hawaii)

<u>UE</u> AAFES(Europe) **X**: Australia **M**: Other Areas

P: Canada

× New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

| Ref. No. | Address | New Parts | Parts No. | Description | Desti- | Re- |
|--|----------------------|--------------|---|---|---------------|-------------|
| 参照番号 | 位 置 | 新 | 部品番号 | 部 品 名 / 規 格 | nation 仕 向 | mark: 備考 |
| C79 ,80 C81 ,82 | | | CEO4FW1V471M CK45FB1H471K | ELECTRO 470UF 35WV CERAMIC 470PF K | | |
| 45 49 J1 J2 •3 | 1B 1C 1C 1C | * | E11-0156-05 E20-0822-05 E13-0223-05 E13-0818-05 | PHONE JACK (3P) PHONES LOCK TERMINAL BOARD(8P) PHONO JACK (2P) PHONO PHONO JACK (8P) INPUT, TAPE 1/2 | | |
| L1 ,2 | | | L39-0085-05 | PHASE-COMPENSATION COIL | | |
| R93 +94 R95 +96 R98 R101-104 VR1 | 2B | * | RS14DB3A100J RS14DB3D561J RS14DB3D560J RD14AB2E221J RO6-5131-05 | FL-PRØØF RS 10 J 1W FL-PRØØF RS 560 J 2W FL-PRØØF RS 56 J 2W FL-PRØØF RD 220 J 1/4W PØTENTIØMETER(100KX2)VØLUME | | |
| VR2 VR3 +4 | 1A 1A | * | R01-5051-05 R06-3049-05 | POTENTIOMETER(200K) BALANCE POTENTIOMETER(10KX2) TREB,BASS | | |
| 91 92 93 94 | 20 20 1B 20 | * | \$42-5041-05 \$42-5042-05 \$42-2110-05 \$40-2323-05 | MULTI-PUSH SW (5 KEY)INPUT SEL MULTI-PUSH SW (5 KEY)INPUT SEL MULTI-PUSH SW SPEAKER PUSH SWITCH (METER RANGE) | | |
| D1 -6 D29 -32 D33 -36 D39 IC1 | | | 152076A DSM1A1 RD16E(B) RD16E(B) AN6556F | DINDE DINDE ZENER DINDE ZENER DINDE IC(NP AMP X2) | | |
| IC1 IC2 Q1 ,2 Q3 ,4 Q5 | | * | NJM4558D(A) NJM2041D-D 2SD637 2SB642 2SC2167(Y+G) | IC(0P AMP X2) IC(0P AMP X2) TRANSISTOR TRANSISTOR TRANSISTOR | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

E: Scandinavia & Europe H:Audio Club K: USA

P: Canada

S: South Africa

<u>UE</u> . AAFES(Europe)

X: Australia M: Other Areas

T: England U: PX(Far East, Hawaii)

× New Parts

Parts without Parts No. are not supplied.

Les articles non mentionnes dans le Parts No. ne sont pas fournis.

Teile ohne Parts No. werden nicht geliefert.

| 本部書号 位 版 新 | Ref. No. | Address | | 1 10 | Des | scription | · · · · · · · · · · · · · · · · · · · | | Re- |
|--|-------------------------------|---------|------------|--|---|-----------------------------|---------------------------------------|------------------|-------------|
| 017 18 | 参照番号 | | Parts 新 | | 部品 | 名/規 | 格 | | marks 備考 |
| 1019 20 | Q15 ,16 Q17 ,18 Q17 ,18 | | * | 2SA1111(0,R) 2SC2921*5 2SC2921*5 | TRANSIST O R TRANSIST O R TRANSIST O R | | | UE KPUM UE | |
| 334 2SA992(F,E) 2SC2320(E,F) 2SC2032(L,K) 3CC2032(L,K) | 019 ,20 019 ,20 021 ,22 | | * | 2SA1215*5 2SA1303*5 2SA992(F,E) | TRANSIST®R TRANSIST®R TRANSIST®R | | | <u>UE</u> | |
| Q39 | 034 035 035 | | | 2SA992(F,E) 2SC232B(E,F) 2SC945(A)(Q,P) | TRANSISTØR TRANSISTØR TRANSISTØR | | | | |
| D7 | Q39 Q40 Q41 | | | 2SA992(F,E) 2SA954(L,K) 2SC2003(L,K) 2SC945(A)(Q) | TRANSISTØR TRANSISTØR TRANSISTØR TRANSISTØR | | | | |
| PL1 | D | | | | | | | | |
| C3 | | | | | | | MONI ETC. | | |
| C13 | C3 ,4 C5 ,6 C7 ,B | | | CEO4FW1C470M CC45FSL1H1O1J CF92FV1H123J | ELECTR® CERAMIC MF | 47UF 100PF 0.012UF | 16WV J J | | |
| C25 C26 C27 ,28 C29 -32 CE04FW1H010M CC45FSL1H150J CF92FV1H334J CF92FV1H334J CE04FW1E100M CE04FW | C13 ,14 C15 ,16 C17 ,18 | | | CF92FV1H102J CE04FW1E470M CK45FF1H103Z | MF ELÉCTRO CERAMIC (| 1000PF 47UF 0.010UF | J 25WV Z | | |
| C34 ,35 C36 C37 -40 C41 ,42 C43 ,44 CC43 ,44 CC594FW1E100M CE04FW1E100M CE04FW1E100 | C25 C26 C27 •28 | | | CEO4FW1HO1OM CEO4FW1HO1OM CC45FSL1H15OJ | ELECTR® ELECTR® CERAMIC | 1. OUF 1. OUF 15PF | 50WV 50WV J | | |
| | C34 +35 C36 C37 -40 | | | CE04FW1E100M CE04FW1E100M CF92FV1H223J | ELECTR® : | 10UF 10UF 0. 022UF | 25WV 25WV J | | |
| C47 -49 | C45 +46 C47 -49 C50 | | | CEO4FW1HR22M CEO4FW1HO10M CK45FF1H472Z | ELECTRO CERAMIC 4 | 0. 22UF 1. OUF 470OPF | 50WV 50WV Z | XTE | |
| C65 ,66 C67 ,68 C69 ,70 C73 C74 CK45FB1H222K CERAMIC ELECTR® 2200F ELECTR® 220UF ELECTR® 47UF CERAMIC | C67 +68 C69 +70 C73 | | | CEO4FW1E221M CEO4FW1E470M CK45FF1H1O3Z | ELECTRO 2 ELECTRO 4 CERAMIC 0 | 220UF 47UF 3. 010UF | 25WV 25WV Z | XTE | |
| C75 -78 | C75 -78 | | | CF92FV1H332J | MF 3 | 3300PF | J | XTE | |

E: Scandinavia & Europe H:Audio Club K: USA

P: Canada

S: South Africa

T: England U: PX(Far East, Hawaii)

X: Australia M: Other Areas

SPECIFICATION

| E | IA |
|--|--|
| Power Amplifier Section Power Output 125 watts* per channel m driven at 8 ohms from 20 H than 0.05% total harmonic of | inimum RMS, both channels z to 20,000 Hz with no more listortion |
| Both Channels Driven into 8 ohms at 1 kHz | |
| Total Harmonic Distortion (AUX – SPKR 8 Ω) at Rated Output, 20 Hz ~ 20,000 Hz at 1/2 Rated Output, | |
| 20 Hz ~ 20,000 Hz at 1/2Rated Output, 1,000 Hz. (PHONO – SPKR 8 Ω : at – 20 c | .0.007% d B VOLUME Level) |
| at Rated Output, 1,000 Hz | 0.02% |
| Intermodulation Distortion (60 Hz:7 kHz = 4:1) | 0.02% at rated power into 8 ohms |
| Damping Factor Frequency Response | 20 (1,000 Hz into 8 ohms) 10 Hz to 100 kHz, |
| Input Sensitivity/Impedance Phono MM TUNER, AUX., TAPE PLAY Signal-to-Noise Ratio (IHF-A) Phono MM Phono MM TUNER, AUX., TAPE PLAY | 150 mV/33 k ohms 73 dB for 2.5 mV input 79 dB for 5.0 mV input |
| Maximum Input Level for Phono MM | 140 mV (RMS), T.H.D. 0.05% at 1 kHz |
| | |
| Tone Control Bass Treble | |
| Loudness Control (at - 30 dB VOLUME Level) Subsonic Filter | |
| General | |
| Power Consumption | 4.1 A (USA and Canada : UL and CSA) |
| AC Outlets (| Except some countries) |
| | N: 420 mm (16-9/16") H: 109 mm (4-5/16") D: 280 mm (11") |
| Weight (Net) | |

* Measured pursuant to Federal Trade Commission's Trade Regulation

rule on Power Output Claims for Amplifier in U.S.A.

| European and U.K. models | |
|--|------------------|
| Power Amplifier Section | |
| Rated Power Output | |
| 1 kHz, 4 ohms | 90 W + 90 W |
| 4 ohms at 60 Hz to 12.5 kHz | |
| no more than 0.7% THD (IEC/NF) | 90 W + 90 W |
| 8 ohms at 60 Hz to 12.5 kHz | |
| no more than 0.7% THD (IEC/NF) | 80 W + 80 W |
| Total Harmonic Distortion | |
| Rated Power Output into 8 ohms | 0 05% |
| Intermodulation Distortion | |
| Frequency Response | |
| | +0 dB, -3 dB |
| S/N Weighted: Rated Output Power (IEC-A) | , |
| () = Unweighted at 50 mW (DIN) | |
| Phono MM | 73 dB (56 dB) |
| TUNER, AUX., TAPE PLAY | 100 dB (56 dB) |
| Damping Factor at 8 ohms, 1,000 Hz | 20 |
| Input Sensitivity/Impedance | |
| Phono MM | |
| TUNER, AUX., TAPE PLAY | 150 mV/33 kΩ |
| Tone Control | |
| Bass 100 Hz | ±10 dB |
| Treble 10 kHz | ±8 dB |
| Loudness Control (- 30 dB) | 8 dB at 100 Hz |
| Subsonic Filter | 18 Hz, 6 dB/oct. |
| General | • |
| Power Consumption | |
| IEC | 230 W |
| Dimensions | |
| | H: 109 mm |
| | |

- IEC/NF -

Kenwood follows a policy of continuous advancements in development. For this reason specifications may be changed without notice.


Kenwood poursuit une politique de progrès constants en ce qui doncerne le développement. Pour cette raison, les spécifications sont sujettes à modifications sans préavis.

Kenwood strebt ständige, Verbesserungen in der Entwicklung an. Daher bleiben Änderungen der technischen Daten jederzeit vorbehalten.

D: 280 mm



WORLD MAP & AREA CODE



Note:

Component and circuitry are subject to modification to insure best operation under differing local conditions. This manual is based on, the U.S. (K) standard, and provides information on regional circuit modification through use of alternate schematic diagrams, and information on regional component variations through use of parts list.

TRIO-KENWOOD CORPORATION

Shionogi Shibuya Building, 17-5, 2-chome Shibuya, Shibuya-ku, Tokyo 150, Japan

KENWOOD ELECTRONICS

DIVISION OF KENWOOD U.S.A. CORPORATION 1315 E. Watsoncenter Rd., Carson, California 90745; U.S.A.

75 Seaview Drive, Secaucus, New Jersey 07094, U.S.A.

TRIO-KENWOOD CANADA INC.,

1070 Jayson Court, Mississauga, Ontario, Canada L4W 2V5

TRIO-KENWOOD ELECTRONICS, N.V.

Leuvensesteenweg 504 B-1930 Zaventem, Belgium

TRIO-KENWOOD ELECTRONICS GmbH

Rembrücker Str. 15, 6056 Heusenstamm, West Germany

TRIO-KENWOOD FRANCE S.A.

5, Boulevard Ney, 75018 Paris, France

TRIO-KENWOOD (AUSTRALIA) PTY, LTD. (INCORPORATED IN N.S.W.)

4E Woodcock Place, Lane Cove, N.S.W. 2066, Australia

KENWOOD & LEE ELECTRONICS, LTD.

Wang Kee Building, 5th Floor, 34-37, Connaught Road, Central, Hong Kong